

# HEGNER MULTIMAX®-22

- |                            |                                |   |
|----------------------------|--------------------------------|---|
| 201 Base                   | 24 Spring                      | 62 Swivel bearing                                     |
| 303 Table                  | 25-28 Screw                    | 65 Rocker switch (wide)                               |
| 304 Upper arm              | 228, 230 Screw                 | 163 Guard   |
| 305 Lower arm              | 31-32 Screw                    | 264 Screw   |
| 306 Front support          | 33 Blade clamp screw           | 265 (B) Variable speed control (board only)           |
| 7 Bellows base             | 34 Allen screw                 | 66 Support roller f. safety spring                    |
| 8 Bushing                  | 35 Screw                       | 267 Safety spring                                     |
| 9 Bushing bolt             | 37-41 Lockwasher               | 370 tension lever only                                |
| 10 Clampholder with spring | 42-44, 47 Washer               | 371 Tension lever rollers only                        |
| 212 Tension rod complete   | 45, 46, 48 Nut                 | 372, 374 Pin  |
| 214 Table guide            | 49 Screw                       | 373 Tension lever roller clips                        |
| 15 Clamp wing nut          | 350 Bladeclamp holder, top     | 465 Switch box complete with switch and speed control |
| 16 Blade mounting device   | 251 Knurl nut                  | 465 H Switch box only                                 |
| 17 Bellows                 | 352 Clamp carriage leaf spring | 200 Holddown arm                                      |
| 318 Airhose                | 54 Rubber bumper               | 101 Holddown arm fork                                 |
| 219 Variable speed motor   | 355 Cover plate                | 102 Thumbscrew  |
| 320 Eccentric              | 56, 57 Washer                  | 103 Plastic insert f. holddown fork                   |
| 221 Connector              | 58 Spring                      |   |
| 22 Thumbscrew, extended    | 59, 60 Washer                  |   |
| 23 Blade clamp             | 61 Bearing bush                |   |

